

9647/SM52/9130 Date Change Instructions

The 9242/9542 are used with the 9130 or SM52 mailing machine. The meters may be black or gray. The 9539 is used with the SM58 Mailing Machine.



Lift the front cover (as in the picture to the left) to access the print wheels. You do not need to turn the power off. Once the cover is raised, the meter will be unable to print.



Using the Ad-Plate tool, a pen or a small screwdriver, turn the year column towards yourself to select "01". The wheels may be a little stiff from being stationary all year.

